



INNER DOOR PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3371435	Door, Inner	4		Actuator Assembly	9		Lid Assembly
		(Includes Items	5	8052027	Wet Agent,	10		Spring, Lid
		2 & 3)			Dispenser	11	3372028	Pin (Lid Hinge)
2	3376066	Latch, Detergent	6	3369000	Draw Bar (Upper			(Also Order
		Dispenser			Dispenser)			ltem #10)
		(Includes Item 3)	7	8066017	Draw Bar (Lower	12	3371710	Screen, Vent
3	3369061				Dispenser)	13	3378134	Cap, Wet-Agent
		Dispenser	8	3368999	Spring (Draw	15	3400815	Screw
		(Includes Item 2)			Bar)	16	3371569	Cover, Drip
		(,	20	8271325	Absorber, Sound

TUB ASSEMBLY PARTS
For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0 (Black) (White) (Biscuit)



TUB ASSEMBLY PARTS

For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0 (Black) (White) (Biscuit)

Illus.	Part		Illus. `	, Part	, , ,	Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3378160	Tub Assembly	17	304392	Screw	35		Panel, Access
2		,	18	661566	Thermostat, Hi–Limit			(Includes Item 53)
3	3368933	Runner (2)	20	301958			3379917	Black
4		Leveler (2)	22	3378595	Bracket,		3379918	White
5	3370389	Screw, Shoulder			Thermostat		8054179	
6	302819	Wheel (2)	23	3370225	Screw	36	302868	=
7	343641	Screw,	24	3369447	Relay	37		Hose, Inlet
8	3378149	Plate, Latch	25	304231	Screw	39		Support, Heater
9	3374720	Screw	28	3379383	Spring, Door (2)	40	8531031	Shield, Sound
10	3376927	Gasket	29	8318218	Housing, Float	41	8529303	Terminal Box
12	8528862	Deflector (2)			Switch	42	300068	Cover Assembly,
13	8519830	Heater	30	3369067	Switch, Float			Terminal Box
		(Includes Item 14)	31	8318219	Cover, Switch	50	3378128	Washer
14	717273	Washer, Rubber (2)			Housing	51	3400014	
15	8268548	Nut (2)	32	8519587	Float & Washer	52	3369138	
		(Heater Terminal)			Assembly	53	3378123	Clip, Grounding
16	8283345	Water Valve	33	717488		54	8052018	Friction Pad
			34		Panel, Toe			
				3368942	Black			
				9742861	White			
				8054181	Biscuit			

PUMP AND MOTOR PARTS For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0

(White) (Black) (Biscuit) Note: The Pump Gasket Must Be Replaced Anytime The Pump Assembly Is Removed And Reinstalled In The Dishwasher. Pump Centering Tool Required For Pump Re–Assembling Order Item 31.

8193745 5

PUMP AND MOTOR PARTS

For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0 (Black) (White) (Biscuit)


			ν.		()		,		
Illus.	Part		Illus.	Part			lus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION		No.	No.	DESCRIPTION
1	9740982	Plate, Perforated (Includes Item 5)	15	3369482	Check Valve (Includes Item 6)		28	3377333	Motor (Includes Item 27)
		(Also Order Item 30)	16 17		Gasket, Pump Pump & Motor				(Also Order Item 30)
2	3367173	See Note A. Base, Inlet			Assembly (Includes Item 16)		29	8281183	See Note A. Screw
2	3307173	(Includes Items	19	3378175	Chopper Kit		29 30	675505	Pump Seal Kit
		1 & 5)	'3	3370173	(Also Order		30	070000	(Includes Items
		(Also Order			Item 30)				4, 12, 13 & 22)
		Item 30)			See Note A.		31	303918	Tool, Pump
		See Note A.	22	302704	Seal, Drain Cover				Centering
3	9741232	Screw	23	3376845	Cover, Drain		32		Clamp, Hose
4	302710	Seal, Inlet Base			(Also Order		33		Hose, Drain
5		Ball, Check			Item 30)		34	3371748	Cap, Drain
6		"O" Ring	l		See Note A.		35		Shaft, Absorber
7	719929		24	8274950	Impeller,		36		Weight, Absorber
9	3384593				Drain Kit		37		Thermostat
10	3400001				(Also Order		38		Seal, O-Ring
11	3378176	Impeller, Wash			Item 30)		39	3376358	Retainer,
		(Includes Items	25	2276457	See Note A.		40	9740674	Thermostat
12	2271152	12 & 13) Screw & Seal	25	3376157	Base, Pump (Includes Item 24)	'	40	9740074	Gasket, Drain Cover
13		Seal, Pump Outlet			(Also Order				Cover
14		Outlet, Pump			Item 30)				
17	0070011	(Includes Item 13)			See Note A.		NO	TE A:	
		(26	3367197					ing Tool Required
					Mounting (4)				-Assembling-
			27	3368270	Slinger			der Item 31	
					(See Note A.)				

DISHRACK PARTS For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0 (Black) (White) (Biscuit) - 13 12 21 18 17 9 20 3 Illus. **Part** No. No. **DESCRIPTION** 8268838 Support, Arm (Also Order Ìtems 2 & 8) 2 303722 Clip 3 8268829 Spray Arm, Upper (Also Order Item 8) 4 8268863 Bumper (2) 8268862 Tower, Pressure 8268820 Wheel & Transport 5 6 6 Assembly (4) 8519578 Dishrack, Lower 7 (Includes Items 4 & 6) 8 8268871 Support Lock, Spray Arm 8268866 Basket, Silverware 9 3376846 Seal, Lower 11 Sprayarm 3385089 Track 12 8524581 Stop, Track (4) 13 17 8268852 Wheel Assembly 8539222 Dishrack, Upper 18 23 (Also Order Item 17) 24 8268826 Clip, Cupshelf 20 8268828 Cupshelf, Small 21 8268874 Sprayarm, Lower 22 22 23 3367910 Cap, Nozzle 719576 Bearing, Nozzle

11

MISCELLANEOUS PARTS

For Models: DU909PWKB0, DU909PWKQ0, DU909PWKT0 (Black) (White) (Biscuit)



Illus.	Part	
No.	No.	DESCRIPTION

3369816 Miscellaneous Parts Bag (Includes 2 Screws & 2 Hose Clamps)

OPTIONAL PARTS

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 72107 Almond 72032 Black

PAINT, PRESSURIZED SPRAY

(12 oz.)

350956 Almond 285006 Superior Black 350942 Primer (White) Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1 qt.)

978883 Almond (Uncut) 799340 Black (Uncut)

DISHRACK REPAIR

675576 Vinyl Touch-Up (Blue) 676453 Vinyl Touch-Up (White) 676455 Vinyl Touch-Up (Grey) Illus. Part

1

No. No. DESCRIPTION

ACCESSORY PARTS

Side Panel Kits: 4317925 White 4317929 Almond

Door Spring Kit: 4318050 Heavy Duty